



# Curb Ramp™ Installation Instructions

## Step 1: Clean

- **For curb-bonded ramps**, sweep and blow the area to remove all dirt and help the primer adhere to the curb surface. Badly soiled curbs may need pressure washing.
- **For easily removable custom-fit curb ramps**, first lay down a protective substrate over the cleaned, dry curb so as not to prime the curb surface directly. Tape down the edges of the substrate. We recommend using a durable rubber membrane.
  - For a list of viable substrates, please visit our website.

## Step 2: Do a “Dry-Run”

Before mixing the material with the adhesive, we recommend that you spread the dry material to fill the curb gap to ensure you have ordered enough. If the material covers the desired area, simply sweep it back into the container and proceed.

## Step 3: Mix

Mix the material with the adhesive using a trowel or mixing drill until the granules are fully coated. You can use the shipping box or an empty 5 gallon bucket for mixing. Begin by pouring in approximately half of the adhesive onto the granules and mixing thoroughly; continue to add adhesive until there are no dry patches and the granules are wet and fully coated. Do not use the entire gallon all at once; there should be a little bit of adhesive left over which can be used for priming (Step 4). The granules should be fully coated but the mix should not be too “soupy”.

**WARNING:** The adhesive is very strong and does not come off easily so we recommend wearing disposable gloves. Exercise caution to avoid leakage over unwanted areas and avoid contact with skin. If necessary, a heavy-duty industrial hand cleaner like GOJO can be used to remove from skin. For Safety Data, visit our website FAQs.

## Step 4: Prime

Prime a thin coat of the remaining adhesive (left over from the mix) to the curb surface using a paint brush.

## Step 5: Spread

Spread the mixture to fill the dried curb curb surface at the desired angle to bridge the gap between the driveway and street. Slope/ feather out the ends to facilitate water drainage; do not create a hard right angle at the ends. Compress/ compact the material using a trowel and shape the edges for clean install lines.

*\*For drainage channel ideas, visit our website.*

## Step 6: Topcoat (Optional)

Apply a thin layer of adhesive to help reinforce the surface of the ramp for longevity and protection from tire friction. Wait until the ramp has dried before applying. For the best coverage, we recommend using a paint roller to apply the adhesive.

*\*Additional adhesive for priming and/ or topcoating can be purchased on our website.*

Allow 24-48 hours to dry.

---

**Disclaimer:** The information contained in this specification conforms to standard detail and product recommendations for the installation of Curb Ramp™ as of the date of publication of this document and is presented in good faith. Curb Ramp™ assumes no liability, expressed or implied, as to the architecture, engineering or workmanship of any project.

To insure that you are using the latest, most complete information, visit the Curb Ramp™ website at [www.curbramp.us](http://www.curbramp.us).