

Product Instructions for Curb Ramp™ Installation

Thank you for choosing Curb Ramp™. Please read the following instructions carefully to ensure a proper and successful installation.

1. Preparation:

- Start by cleaning the area thoroughly to remove dirt and debris. Use a broom, sweep, or blow to clear the curb surface. For heavily soiled curbs, pressure washing may be necessary.
- If you want the curb ramp to be removable, lay down a protective substrate over the cleaned and dry curb. This will prevent the primer from directly contacting the curb surface. Use a durable rubber membrane and securely tape down the edges of the substrate to the curb. Contact us or visit our website for the latest recommendations on suitable substrates.

Tip: Before mixing the material with the adhesive, perform a "Dry-Run" by spreading the dry material to fill the curb gap. This will ensure you have ordered enough material. If the material covers the desired area, sweep it back into the container and proceed.

2. Mixing:

- Mix the material with the adhesive thoroughly using a trowel or mixing drill. Ensure that all the granules are fully coated.
- You can use the shipping box, an empty 5-gallon bucket, or a heavy-duty trash bag* for mixing.
- Start by pouring approximately ¾ of the adhesive onto the granules and mix until there are no dry patches and the granules are fully coated. Add more adhesive if needed, but avoid using the entire gallon all at once. Make sure there are no dry patches that could compromise the ramp's integrity.
- The granules should be fully coated, but the mix should not be too "soupy." A little bit of adhesive should be left over for priming. If not, it's okay.

Warning: The adhesive is very strong and difficult to remove, so we recommend wearing disposable gloves. Take care to avoid leakage over unwanted areas and prevent contact with eyes and skin. If necessary, a heavy-duty industrial hand cleaner like GOJO can be used to remove the adhesive from the skin. Chemical specifications and safety data can be found on the adhesive product page at: <https://curbramp.us/shop/topcoats/1-gallon-adhesive/>

3. Priming:

- Use the leftover adhesive to prime the curb surface. Apply it using a paint roller or brush to ensure a good bond.

4. Spreading and Shaping:

- Spread the mixture over the dried curb surface, filling the gap between the driveway and the street at the desired angle. Avoid creating hard right angles at the ends.
- Slope and feather out the ends to facilitate water drainage. For drainage channel ideas, please visit our website.
- Shape and compress the material thoroughly using a trowel, and form the edges for clean install lines. Tamp it down well to ensure there are no air gaps.
- Allow the installation to dry for 24-48 hours.

Longevity & Maintenance:

To extend the lifespan of your curb ramp and address visible signs of wear and tear, you can apply a topcoat using a paint brush. This will create a protective lining. We recommend using a standard asphalt emulsion sealer, which can be purchased at any local hardware store. Feel free to contact us if you have any questions.

Disclaimer:

The provided specification for installing Curb Ramp™ adheres to standard details and product recommendations as of the publication date, presented in good faith. Curb Ramp is not liable for any damages arising from the use or misuse of their products or services and assumes no liability for the architecture, engineering, or workmanship of any project. To ensure you have the latest and most complete information, please visit our website at www.curbramp.us.

We appreciate your trust in Curb Ramp™ and hope you enjoy your newly installed curb ramp. If you have any further inquiries, do not hesitate to contact us.